



## ... using the Olfa Scriber

The **Olfa Scriber** (known as a *Pcutter*) is such a versatile little tool you'll wonder how you lived without it. Designed for cutting and scribing Laminates, it works on resins & plastics also. Whether scribing detail lines or cutting plastics, you just have to have one!



### Scribing New Detail Lines

- hold the Scriber with the tip to the plastic and your forefinger resting on top, similar to holding a scalpel. Using a ruler as a guide (metal ruler is recommended) and pushing firmly, move the Scriber down the plastic. Don't push excessively hard, you may slip. You will see a fine plastic slither come away. Repeat this process until depth required. of detail is achieved.



### Score & Snap

- hold the Scriber with the tip to the plastic and your forefinger resting on top, similar to holding a scalpel. Using a ruler as a guide (metal ruler is recommended) and pushing firmly, move the Scriber down the plastic. Don't push excessively hard, you may slip. You will see a fine plastic slither come away. Repeat this process two to three times, along the same line.
- Then, holding the plastic in both hands, bend gently until it snaps. You should have a clean, smooth break.

### Enhancing Detail Lines V1

- hold the Scriber with the tip to the plastic and your forefinger resting on top, similar to holding a scalpel. Pressing firmly, slowly draw down with the Scriber, following the already scribed detail line. Don't push too hard, or go too quickly, you may slip. Repeat process until detail required is reached. (We have shown detailing a plastic airplane part detail line)



### Enhancing Detail Lines V2

- hold the Scriber with the tip to the plastic at approx 10° angle and the resting on your thumb. Pressing firmly, slowly draw down with the Scriber, following the already scribed detail line. Don't push too hard, or go too quickly, you may slip. Repeat process until you reach detail required. (We have shown detailing clothing on a resin figure.)